



## **M.A.T. Relocation Kit**

### **3.SEN115**

1. Find mat sensor on the bottom of the plenum right in front of the distributor.
2. Disconnect the harness from the sensor, follow the wires back a few inches until you find another connector in the main harness at the firewall.
3. Disconnect this connector, and discard this harness.
4. Connect the new harness to this connector.
5. The sensor can be relocated anywhere in the air stream in front of the throttle body, in the ductwork or in the air box. After you locate your mounting position, drill a hole .720" or 23/32" in size.
6. Insert grommet into hole and insert sensor.
7. Connect other end of harness to the sensor.

Your computer will now have a more accurate air temperature reading.